

Can't find a DJI product / accessory / spare-part in our WH ? Have a look and see if we have it here!

Orig. DJI Spare Parts in Boston WH – RMA workshop stock inventory only. Actualized pr.

04.01.21

If the product has a C5 Product nr. 48nnnn in column D, it can be ordered here <http://www.bostonnordic.com/login.aspx>

How to order products NOT listed in our web-shop

- 1) In the spare-part list copy the whole line of the product(s) you want
- 2) Paste them into a mail to Fritz (FF) ff@boston.dk – adjust the number of pieces you want to buy
- 3) Add the delivering address and your Signature. NB: INCLUDE your Boston customer account-nr.
- 4) FF replies with a price proposal.
- 5) After accept we create an order confirmation, send the products and invoice the normal way.
- 6) The list is actualized after every order confirmation and whenever new products are added.

DJI-SKU / FR-sku	Items - sorted by product & name	In stock	in Boston
Inspire 1		pieces	C5 Product-Nr
40882	DJI Inspire 1 Part 02 center frame component	1	to be created
40664	DJI Inspire 1 part 09 landing gear	6	
40735	DJI Inspire 1 Part 10 auxiliary RIGHT arm component	4	
40663	DJI Inspire 1 Part 11 auxiliary LEFT arm component	4	
40889	DJI Inspire 1 PART 21 5.8G&2.4G dualfrequency antenna	6	
40890	DJI Inspire 1 PART 22 2.4G single frequency antenna	6	
40891	DJI Inspire 1 PART 23 aircraft body screw kit	5	
	DJI Inspire 1 Part 42 Gimbal Rubber Dampers & EVA foam	1	
40861	DJI Inspire 1 Pro motor+ESC (CCW:M1,M3) V2.0	5	to be created
40860	DJI Inspire 1 Pro motor+ESC (CW:M2,M4) V2.0	5	to be created
40665	DJI Inspire 1 left arm component(large plaid)	6	to be created
40733	DJI Inspire 1 right arm component(large plaid)	2	to be created
40884	DJI Inspire 1 Sticker	5	
CP.BX.000021	Inspire Part 13 180W Power Adaptor(no AC cable)	1	481551
CP.BX.000023	Inspire Part 15 Battery Heater	5	481575
CP.ZM.000308	Inspire Part 16 Gimbal Cover (pair) = Osmo/Ins1 Part 39	9	481941
CP.BX.000025	Inspire Part 17 Fast-mounting Gimbal Port Cable	1	481587
	Inspire Part 30 Fast-mounting Gimbal Port pcba	4	
CP.BX.000039	Inspire Part 31 Airframe Top Cover	3	480205
CP.BX.000040	Inspire Part 32 Aircraft Nose Cover	1	480206
CP.BX.000041	Inspire Part 33 Left & Right Arm Supports	1	480207
CP.BX.000042	Inspire Part 34 Remote Controller Cable Kit	7	
CP.BX.000044	Inspire Part 35 Filter Kit	1	481564
CP.BX.00004?	Inspire Part 36 Battery Compartment	5	
CP.BX.000045	Inspire Part 37 Airframe Bottom Cover	2	
CP.BX.000046	Inspire Part 38 Sticker	6	
	Inspire Part 39 Vision Position Module	1	to be created
CP.BX.000051	Inspire Part 43 Left & Right Cable Clamp	10	
CP.BX.000054	Inspire Part 46 Airframe Tag	5	
CP.BX.000055	Inspire Part 47 Bottom GPS Cover	5	
CP.BX.000057	Inspire Part 48 Taillight cover	6	480211
	Inspire Part 49 Gimbal Connection Gasket	17	
CP.BX.000128	Inspire Part 52 Self-tightening props	29	481545
CP.BX.000062	Inspire Part 53 propeller Installation Kits	24	481541
CP.BX.000009	Inspire Part 54 Remote Controller	1	481530
CP.BX.000080	Inspire Part 61 ND8 Filter Kit	1	481566

CP.BX.000113	Inspire Part 72 Landing gear Riser Kit	8	481544
YC.SJ.J00691.01	Inspire 1 + 2 Rubber Dampers to gimbal absorbing plate	30	
CP.BX.000017	Inspire Part 91 Landing gear	6	
Inspire 2		pcs	C5 Product-Nr
	DJI Inspire 2 Vibration Absorbing Board Part 23	2	to be created
	DJI Inspire 2 Mobile Device Holder Adapter Part 62	4	
M200		pcs	
41182	DJI Matrice 200/210 Antenna Mount Module	0	to be created
CP.HY.00000071.01	DJI Matrice 200/210 Landing Gear Part 14	0	481688
CP.HY.00000076.01	DJI Matrice 200/210 Landing Gear Module Part 15	0	481689
Mavic Mini + Air 1		pcs	C5 Product-Nr
CP.MA.SS000020.01	DJI Mavic Mini Front Arm Module (Right)	0	
CP.MA.SS000022.01	DJI Mavic Mini Front Arm Module (Left)	0	
CP.MA.SS000021.01	DJI Mavic Mini Rear Arm Module (Right)	0	
CP.MA.SS000023.01	DJI Mavic Mini Rear Arm Module (Left)	0	
YC.WJ.CC000178.02	DJI Mavic Mini Front Aircraft Arm Rotation Axis	4	
YC.WJ.CC000177.02	DJI Mavic Mini Rear Aircraft Arm Rotation Axis	4	
BC.MA.SS000115.01	DJI Mavic Mini Gimbal and Camera Module	1	
YC.SJ.WS003402.03	DJI Mavic Mini Gimbal Cover	5	
BC.MA.SS000110.01	DJI Mavic Mini Propeller (CCW)	8	
BC.MA.SS000111.01	DJI Mavic Mini Propeller (CW)	8	
YC.SJ.WS003302.02	DJI Mavic Mini Control Stick Head	2	
BC.MA.SS000113.01	DJI Mavic Mini 360° Propeller Guard (Left)	2	
BC.MA.SS000114.01	DJI Mavic Mini 360° Propeller Guard (Right)	2	
YC.XC.XX000093.02	DJI Mavic Mini Micro USB-Type C Cable (RH)	2	
YC.XC.XX000091.02	DJI Mavic Mini Remote Controller Micro USB Cable (RH)	2	
YC.XC.XX000373.02	DJI Mavic Mini Micro USB - Lightning Cable (RH)	3	
BC.MA.SS000127.01	DJI Mavic Mini Remote Controller (CE)	0	
41224	DJI Mavic Air Front Left Arm (Red)	1	to be created
41222	DJI Mavic Air Front Left Arm (White)	5	to be created
41221	DJI Mavic Air Front Right Arm (Black)	0	to be created
41225	DJI Mavic Air Front Right Arm (Red)	0	to be created
41223	DJI Mavic Air Front Right Arm (White)	3	to be created
41226	DJI Mavic Air Rear Left Arm	0	to be created
41227	DJI Mavic Air Rear Right Arm	0	to be created
41231	DJI Mavic Air Vibration Absorbing Board	5	
Mavic Pro + Platinum		pcs	C5 Product-Nr
40868	DJI Mavic Aircraft Frame Flexible Flat Cable (GKAS)	5	
40867	DJI Mavic Compass Board (GKAS)	6	
40871	DJI Mavic Fan (GKAS)	5	
40866	DJI Mavic Flight controller ESC board (GKAS)	1	to be created
41150	DJI Mavic Front Axis	8	
40870	DJI Mavic Front Vision (GKAS)	2	
40966	DJI Mavic Gimbal Mounting Bracket	8	to be created
40876	DJI Mavic Gimbal Vibration Absorbing Board (GKAS)	0	
40865	DJI Mavic GPS Module (GKAS)	2	to be created
40960	DJI Mavic Power Board (GKAS)	2	
CP.PT.S00040	DJI Mavic Power Interface Boards	1	
40959	DJI Mavic Pro Aircraft Appearance Sticker (GKAS)	5	
40869	DJI Mavic Pro Bottom Shell (GKAS)	4	to be created

40863	DJI Mavic Middle Frame (GKAS)	10	to be created
40864	DJI Mavic Pro Upper Shell (GKAS)	5	to be created
40961	DJI Mavic Pro Core Board A (GKAS)	1	to be created
40874	DJI Mavic Pro Back Left Motor Arm (GKAS)	4	to be created
40875	DJI Mavic Pro Back Right Motor Arm (GKAS)	5	to be created
40872	DJI Mavic Pro Front Left Motor Arm (GKAS)	5	to be created
40873	DJI Mavic Pro Front Right Motor Arm (GKAS)	8	to be created
40877	DJI Mavic Pro Gimbal & Camera(GKAS) (Pro/Platinum)	4	to be created
41230	DJI Mavic Pro Remote Controller 5D Button	5	
40963	DJI Mavic RC Lower Cover (GKAS)	1	
40962	DJI Mavic Wi-Fi Board (GKAS)	3	
41219	DJI Mavic Pro Platinum Bottom Shell	3	to be created
41166	DJI Mavic Pro Platinum Middle Frame Module (PY)	6	to be created
41181	DJI Mavic Pro Platinum Upper Cover (GKAS)	3	to be created
41179	DJI Mavic Pro Platinum Left Front Motor Arm	0	to be created
41167	DJI Mavic Pro Platinum Left Rear Motor Arm (PY)	0	to be created
41177	DJI Mavic Pro Platinum Right Front Motor Arm	0	to be created
41172	DJI Mavic Pro Platinum Right Rear Motor Arm (PY)	0	to be created
Mavic 2		pcs	C5 Product-Nr
Amazon	DJI Mavic 2 to Crystal Sky Adapter / Charging Cable	3	
41370	DJI Mavic 2 Front Arm Axis (right)	0	
41383	DJI Mavic 2 Front Arm Module (Left)	0	to be created
41385	DJI Mavic 2 Front Arm Module (Right)	0	to be created
41371	DJI Mavic 2 Front Cover	0	
41378	DJI Mavic 2 Gimbal Mounting Cover	4	to be created
41374	DJI Mavic 2 Lower Cover Module	1	to be created
41377	DJI Mavic 2 Middle Frame Module	5	to be created
41369	DJI Mavic 2 Rear Arm Axis	4	
41384	DJI Mavic 2 Rear Arm Axis Bracket (Left)	5	
41373	DJI Mavic 2 Rear Arm Axis Bracket (Right)	5	
41381	DJI Mavic 2 Rear Arm Module (Left)	0	to be created
41387	DJI Mavic 2 Rear Arm Module (Right)	0	to be created
41372	DJI Mavic 2 Rear Landing Gear (Left)	4	
41379	DJI Mavic 2 Rear Landing Gear (Right)	4	
41382	DJI Mavic 2 Upper Cover Module	1	
41386	DJI Mavic 2 Pro Gimbal and Camera	0	to be created
41375	DJI Mavic 2 Zoom Gimbal and Camera	3	to be created
CP.MA.0000058.01	DJI Mavic 2 Battery to Power Bank adpt	3	480011
Phantom 3		pcs	C5 Product-Nr
40881	P3 connecting cable set (Sta)	2	
CP.PT.000187	P3 Part 01 gps module (pro/adv)	1	481365
CP.PT.000188	P3 Part 02 Propeller Guard	4	481409
40675	P3 Part 04 inner power port module	2	
CP.PT.000192	P3 Part 06 HD Camera (adv)	1	481345
CP.PT.000193	P3 Part 07 2312 Motor (CCW) (Pro/Adv)	12	481347
CP.PT.000194	P3 Part 08 2312 Motor (CW) (Pro/Adv)	10	481348
CP.PT.000197	P3 Part 11 Compass	8	481368
CP.PT.000207	P3 Part 21 Battery Charger 57W	0	481350
CP.PT.000215	P3 Part 29 Landing gear (Pro/Adv)	15	481288
CP.PT.000216-B	P3 Part 30-1 Bottom Shell (Pro/Adv)	1	481375

CP.PT.000216-T	P3 Part 30-2 Top Shell (Pro/Adv) (CP.PT.S00001 ???)	5	481375
	P3 Part 35 OFDM Receiver Module	2	to be created
	P3 Part 36 Visual Position System (Pro/Adv)	2	to be created
CP.PT.000225	P3 Part 39 Camera Vibr. Absorbing Board (Pro/Adv)	15	481379
CP.PT.000226	P3 Part 40 Vibration Absorbing Rubber Ball	3	481380
CP.PT.000227	P3 Part 41 Screw Set	4	
CP.PT.000228	P3 Part 42 Cable Set	10	
CP.PT.000229	P3 Part 43 Sticker Set	5	
CP.PT.000232	P3 Part 46 ND4 Filter	1	481374
	P3 Part 47 USB-Port Cable	10	
CP.PT.000241	P3 Part 54 HDMI Output Module (Pro/Adv)	9	481371
CP.PT.000242	P3 Part 55 ND8 Filter (Pro/Adv)	1	481372
CP.PT.000243	P3 Part 56 ND16 Filter (Pro/Adv)	3	481673
40672	P3 Part 67 GPS module (sta)	2	
	P3 Part 69 5,8G Receiver Antenna (Sta)	4	
40676	P3 Part 69 receiver antenna 5.8G (sta) (2pcs)	4	
	P3 Part 71 Landing gear (Sta)	5	to be created
40879	P3 Part 72 Shell (top & bottom) (Sta)	5	
CP.PT.000260	P3 Part 76 ESC central board & mc & receiver 5.8ghz (Sta)	1	481385
	P3 Part 82 Sticker Set (Sta)	3	
CP.PT.000267	P3 Part 83 Camera Vibrat. Absorbing Board (Sta)	1	481386
CP.PT.000269	P3 Part 85 Flex Gimbal Flat Cable(Sta)	2	to be created
40666	P3 Part 97 2.4g Antenna (sta)	4	
	P3 Part 101 LED (Sta)	10	
	P3 Part 102 LED (Pro/Adv)	8	
	P3 Part 106 Center Board Component	4	
40986	P3 Part 117 Damping Rod	37	
CP.PT.000321	P3 Part 119 Gimbal w 4K Camera	1	481388
40677	P3 standard aircraft body mainboard (sta)	8	
Phantom 4		pcs	C5 Product-Nr
	P4 Landing Gear Antenna Cover 1	3	
	P4 Landing Gear Antenna Cover 2	3	
	P4 Landing Gear Antenna Cover 3	3	
	P4 Landing Gear Antenna Cover 4	3	
CP.PT.S00024	P4 Part ?? 9450S QR Propeller Base CW NB: only CW!	8	
CP.PT.000339	P4 Part ?? Gimbal & Camera refurbished	2	481452
40683	P4 Part 01 GPS module	3	to be created
CP.PT.000337	P4 Part 02 Propeller Guard	7	481441
CP.PT.000338	P4 Part 03 aircraft internal power port module	3	481457
CP.PT.000343	P4 Part 08 Battery Charging Hub	7	481453
CP.PT.000334	P4 Part 09 100W Power Adaptor (without AC cable)	0	481442
CP.PT.000353	P4 Part 18 Remote Controller without box	1	481454
CP.PT.000358	P4 Part 23 2312S Motor_CCW	5	to be created
CP.PT.000359	P4 Part 24 2312S Motor_CW	1	to be created
CP.PT.000362	P4 Part 27 Shell (up+down)	1	481458
CP.PT.000362	P4 Part 27-1 Upper Shell (GKAS)	4	481458
CP.PT.000362	P4 Part 27-2 middle shell (GKAS)	4	481458
40862	P4 Part 28 Downward Facing Vision Positioning Module	5	to be created
CP.PT.000366	P4 Part 31 Mobile Device Holder	3	481456
CP.PT.000368	P4 Part 33 Screw Set	5	481436

	P4 Part 34 Cable Set	3	
CP.PT.000370	P4 Part 35 Gimbal Lock	4	481451
CP.PT.000371	P4 Part 36 Flexible Gimbal Flat Cable	3	481435
CP.PT.000376	P4 Part 41 LED	26	
CP.PT.S00032	P4 Part 43 main controller	3	to be created
40645	P4 Part 44 ESC Center Board(left)	7	to be created
40646	P4 Part 45 ESC Center Board(right)	4	to be created
CP.PT.000382	P4 Part 47 Replica Model	1	481460
CP.PT.000384	P4 Part 49 LED light cover	22	481467
	P4 Part 50 cable mix ???	2	
40690	P4 Part 50 flat cable & cable	4	
40691	P4 Part 51 forward vision module	2	to be created
40692	P4 Part 52 3-in-1 board module	1	to be created
40693	P4 Part 53 main controller vibration	4	
Phantom 4 Pro		pcs	C5 Product-Nr
41232	DJI Phantom 4 Pro Compass Connection Cable	4	
41419	DJI Phantom 4 Pro Landing Gear Antenna Cover 1	13	
41392	DJI Phantom 4 Pro Landing Gear Antenna Cover 2	13	
41393	DJI Phantom 4 Pro Landing Gear Antenna Cover 3	13	
41420	DJI Phantom 4 Pro Landing Gear Antenna Cover 4	13	
40946	DJI Phantom 4 Pro Left & Right Landing Gear (GKAS)	0	to be created
40951	DJI Phantom 4 Pro Left ESC Board (GKAS)	1	to be created
CP.PT.S00070	DJI Phantom 4 Pro Part 01 GPS Module (GKAS)	2	to be created
CP.PT.S00072	DJI Phantom 4 Pro Part 03 Sub G Antenna (GKAS)	5	
CP.PT.S00073	DJI Phantom 4 Pro Part 04 Quick Release Prop Mount.Plate	10	
CP.PT.S00078	DJI Phantom 4 Pro Part 09 Gimbal Vibration Absorbing Board	5	to be created
CP.PT.S00080	DJI Phantom 4 Pro Part 11 Main Controller (GKAS)	2	to be created
40954	DJI Phantom 4 Pro Part 15 3-in-1 Board Module (GKAS)	1	to be created
40955	DJI Phantom 4 Pro Part 16 Flat Cable & Cable (GKAS)	4	to be created
40956	DJI Phantom 4 Pro Part 17 Forward Vision Module (GKAS)	2	to be created
40957	DJI Phantom 4 Pro Part 18 Rearward Vision Module (GKAS)	2	to be created
CP.PT.000615	DJI Phantom 4 Pro Part 78 LED Cover (4pcs)	6	480210
40943	DJI Phantom 4 Pro Power Interface Module (GKAS)	2	
40952	DJI Phantom 4 Pro Right ESC Board (GKAS)	1	to be created
40947	DJI Phantom 4 Pro Upper Shell (GKAS)	4	
CP.PT.00000278.01	DJI Phantom 4 Pro V2.0 Gimbal & Camera Part 141	1	480055
41269	DJI Phantom 4 Pro V2.0 Left Landing Gear	3	to be created
41234	DJI Phantom 4 Pro V2.0 Long Gimbal Flat Cable	0	to be created
41270	DJI Phantom 4 Pro V2.0 Right Landing Gear	8	to be created
41235	DJI Phantom 4 Pro V2.0 screw pack (GKAS)	4	
41170	DJI P4P Obs. 2312S Motor (Black)	3	
41165	DJI P4P Obs. Middle Frame (black)	4	
41168	DJI P4P Obs. Landing Gear Antenna Cover 1 (Black)	11	
41173	DJI P4P Obs. Landing Gear Antenna Cover 2 (Black)	1	
41174	DJI P4P Obs. Landing Gear Antenna Cover 3 (Black)	1	
41169	DJI P4P Obs. Landing Gear Antenna Cover 4 (Black)	9	
41178	DJI P4P Obs. Left Landing Gear Module (black)	3	
41175	DJI P4P Obs. Right Landing Gear Module (black)	4	
41185	DJI P4P Obs. Upper Cover (with logo) (Black) V3	3	
SPARK		pcs	C5 Product-Nr

41083	DJI Spark Gimbal and Camera Module	2	to be created
	DJI Spark LED covers + mounting rings (FL,FR,BL,BR)	12	
	DJI Spark Top-Shells (red, blue, yellow, green, white,)	15	
Focus			C5 Product-Nr
CP.ZM.000238	Focus Remote controller for Inspire, PRO & RAW	1	481596
CP.ZM.000287	Focus Part 3 2.4G Antenna	2	481652
CP.ZM.000292	Focus Part 8 Lens Gear Ring (60MM)	1	481657
CP.ZM.000293	Focus Part 9 Lens Gear Ring (70MM)	1	481558
CP.ZM.000296	Focus Part 12 Neck Strap	1	481563
CP.ZM.000298	Focus Part 14 Motor Quick-release Mount	1	481511
CP.ZM.000299	Focus Part 15 Motor Quick-release Mount (extd. by 40mm)	1	481513
CP.ZM.000300	Focus Part 16 Motor Gear(MOD 0.8)	1	481512
Ronin			C5 Product-Nr
CP.ZM.000098	Ronin Part 4 Lens Support Thumbscrew	1	481878
CP.ZM.000100	Ronin Part 6 Battery Charger	4	481815
CP.ZM.000104	Ronin Part 10 Clamb Knob (6pcs)	3	to be created
CP.ZM.000105	Ronin Part 11 Vertical Bar Clamb (2Pcs)	1	to be created
CP.ZM.000106	Ronin Part 12 Base Clamb Assembly	2	to be created
CP.ZM.000111	Ronin Part 17 Power Distribution Box	1	to be created
CP.ZM.000113	Ronin Part 19 Camera Screw 1/4 (2pcs)	1	480365
CP.ZM.000114	Ronin Part 20 Camera Screw 3/8 (2pcs)	1	480364
CP.ZM.000139	Ronin Part 32 Lens support (103mm)	1	481879
YC.WJ.L00479.02	Ronin Screw M2x4	2	
BC.ZM.SS000090.02	Ronin Grip Handle	4	
	Ronin (M) Part 41 Battery Power distributor	1	to be created
Ronin-M			C5 Product-Nr
CP.ZM.000182	Ronin M Part 6 Center Handle Set	1	to be created
CP.ZM.000183	Ronin M Part 7 Locking Knob - sell pr. piece	5	to be created
CP.ZM.000184	Ronin M Part 8 Pitch Interlocking Adjustment Buckle	1	to be created
CP.ZM.000185	Ronin M Part 9 Camera lock	1	to be created
CP.ZM.000186	Ronin M Part 10 Carbon Top Handle Bars	1	480349
CP.ZM.000188	Ronin M Part 12 Regulation Of Interlocking, Pan Adjust Buckle	1	to be created
CP.ZM.000190	Ronin M Part 14 Drop Proof Kit	1	to be created
CP.ZM.000193	Ronin M Part 17 Remote Controller	1	480166
CP.ZM.000208	Ronin M Part 22 Charger	1	481876
CP.ZM.000229	Ronin M Part 29 25W BATTERY CHARGER (EU)	0	481846
Ronin-S			C5 Product-Nr
YC.SJ.MQ000002.01	Ronin S Rubber pads (pair) for long Cam plate	10	to be created
YC.BZ.BB000027.01	Ronin S Storage case	1	
CP.RN.0000005.01	Ronin S 1/4 srew for long Cam plate	50	to be created
	Ronin S Grip-Joystick	4	
	Ronin S Grip-Joystick protectiveRubber ring	4	
Osmo			C5 Product-Nr
CP.ZM.000237	Osmo Part 4 Car Mount	4	481929
CP.ZM.000239	Osmo Part 5 Straight Extension Arm	1	481930
CP.ZM.000246	Osmo Part 10 Intelligent Battery Charger(EU)	7	481934
CP.ZM.000260	Osmo Part 26 Carry Case	2	481937
CP.ZM.000279	Osmo Part 35 - Articulating Locking Arm	1	481938
CP.ZM.000307	Osmo Part 38 - Quick Release 360 Mic Mount	1	481940
CP.ZM.000308	Osmo-Inspire Part 39 - Gimbal Cover	4	481941

CP.ZM.000310	Osmo Part 40 - Accessory for Universal Mount - Rotatable Cold Shoe for Universal Mount	3	481942
CP.ZM.000311	Osmo Part 41 - Accessory for Universal Mount - 1/4" & 3/8" Mounting Adapter for Universal Mount	1	481943
CP.ZM.000321	Osmo Part 44 - DJI FM-15 FlexiMic	24	481944
CP.ZM.000344	Osmo Part 47 Z-Axis	2	481948
CP.ZM.000360	Osmo part 49 External Battery Extender	4	481949
CP.ZM.000364	Osmo Part 50 Battery (2PIN) ti DC Power Cable	2	481950
CP.ZM.000363	Osmo Part 51 Battery (10PIN) ti DC Power Cable	2	481951
	Osmo Screw set	1	
	Osmo Joystick	2	
	Osmo Dial Component	2	
	Osmo Front Shell component	2	
Div.& ZENMUSE		pcs	C5 Product-Nr
ZenmuseX5-part3	ZENMUSE X5 Balancing Ring for Panasonic 15mm,F/1.7 ASPH PZENMUSE	5	to be created
ZenmuseX5-part4	ZENMUSE X5 Balancing Ring for Olympus 17mm f1.8 Lens	4	to be created
ZenmuseX5-part5	ZENMUSE X5 Balancing Ring for Olympus 14-42 f3.5-6.5 EZ Lens	4	to be created
CP.ZM.000024	DJI Zenmuse H3-2D	2	
CP.ZM.000054	DJI Zenmuse ZH3-2D, Part 37	14	
CP.ZM.000070	DJI ZH3-3D Cable Pack Pa	5	
CP.ZM.000152	DJI ZH4-3D Cable Pack Package	4	
CP.ZM.000151	DJI ZH4-3D Screws Pack	5	
CP.WK.000036	DJI A2 Can-Bus Cable A2	1	
CP.AL.000015	DJI Remote Controller Cables Part8 LightBridge	2	
CP.ZM.000088	DJI Lightbridge Z15-Gh4 HDMI Cable Part 11	3	
	DJI Lightbridge 2 Antennas&Antenna Holder Part 12	2	

Can't find a DJI product / accessory / spare-part in our WH ? Have a look and see if we have it here!

Orig. DJI Spare Parts in Boston WH – RMA workshop stock inventory only. Actualized pr.

see on top

If the product has a C5 Product nr. 48nnnn in column D, it can be ordered in our webshop <http://www.bostonnordic.com>,

How to order products NOT listed in our web-shop

- 1) In the spare-part list copy the whole line of the product(s) you want
- 2) Paste them into a mail to Fritz (FF) ff@boston.dk – adjust the number of pieces you want to buy
- 3) Add the delivering address and your Signature. NB: INCLUDE your Boston customer account-nr.
- 4) FF replies with a price proposal.
- 5) After accept we create an order confirmation, send the products and invoice the normal way.
- 6) The list is actualized after every order confirmation and whenever new products are added.