

Can't find a DJI product / accessory / spare-part in our WH ? Have a look and see if we have it here!

Orig. DJI Spare Parts in Boston WH – RMA workshop stock inventory only. Actualized pr.

13.09.19

Here our available DJI spare-parts, which are NOT listed in our official web-shop.

How to order:

- 1) In the spare-part list copy the whole line of the product(s) you want
- 2) Paste them into a mail to Fritz (FF) ff@boston.dk – adjust the number of pieces you want to buy
- 3) Add the delivering address and your Signature. NB: INCLUDE your Boston customer account-nr.
- 4) FF replies with a price proposal.
- 5) After accept we create an order confirmation, send the products and invoice the normal way.
- 6) The list is actualized after every order confirmation and whenever new products are added.

SKU / FR-sku	Items - sorted by product & name	In stock
Inspire 1		pieces
40663	DJI Inspire 1 Part11 auxiliary LEFT arm component	4
40735	DJI Inspire 1 Part10 auxiliary RIGHT arm component	4
40664	DJI Inspire 1 part9 landing gear	6
40665	DJI Inspire 1 left arm component(large plaid)	6
40733	DJI Inspire 1 right arm component(large plaid)	2
40889	DJI Inspire 1 PART 21 5.8G&2.4G dualfrequency antenna	6
40890	DJI Inspire 1 PART 22 2.4G single frequency antenna	6
40891	DJI Inspire 1 PART 23 aircraft body screw kit	5
40861	DJI Inspire 1 Pro motor+ESC (CCW:M1,M3) V2.0	5
40860	DJI Inspire 1 Pro motor+ESC (CW:M2,M4) V2.0	5
40882	DJI Inspire 1 Part02 center frame component	2
40884	DJI Inspire 1 Sticker	5
	DJI Inspire 1 Part42 Gimbal Rubber Dampers & EVA foam	1
CP.BX.000011	Inspire Part 3 100W power adaptor (no AC cable)	2
CP.BX.000021	Inspire Part 13 180W Power Adaptor(no AC cable)	1
CP.BX.000023	Inspire Part 15 Battery Heater	5
	Inspire Part 16 Gimbal Cover (2)	9
CP.BX.000025	Inspire Part 17 Fast-mounting Gimbal Port Cable	1
	Inspire Part 30 Fast-mounting Gimbal Port pcba	4
CP.BX.000039	Inspire Part 31 Airframe Top Cover	0
CP.BX.000040	Inspire Part 32 Aircraft Nose Cover	0
CP.BX.000041	Inspire Part 33 Left & Right Arm Supports	1
CP.BX.000042	Inspire Part 34 Remote Controller Cable Kit	7
CP.BX.000043	Inspire Part 35 Filter Kit	1
CP.BX.000044	Inspire Part 36 Battery Compartment	5
CP.BX.000045	Inspire Part 37 Airframe Bottom Cover	2
CP.BX.000046	Inspire Part 38 Sticker	6
	Inspire Part 39 Vision Position Module	1
CP.BX.000051	Inspire Part 43 Left & Right Cable Clamp	10
CP.BX.000054	Inspire Part 46 Airframe Tag	5
CP.BX.000055	Inspire Part 47 Bottom GPS Cover	5
999	Inspire Part 48 Taillight cover	6
	Inspire Part 49 Gimbal Connection Gasket	17
CP.BX.000128	Inspire Part 52 Self-tightening props	30
CP.BX.000062	Inspire Part 53 propeller Installation Kits	20
CP.BX000009	Inspire Part 54 Remote Controller	1
	Inspire Part 61 ND8 Filter Kit	1

CP.BX.000113	Inspire Part 72 Landing gear Riser Kite	6
CP.BX.000017	Inspire Part 91 Landing gear	6
Inspire 2		pcs
	DJI Inspire 2 Vibration Absorbing Board Part 23	1
	DJI Inspire 2 Mobile Device Holder Adapter Part 62	4
M200		pcs
41182	DJI Matrice 200 Antenna Mount Module	2
41176	DJI Matrice 200 Landing Gear	4
41180	DJI Matrice 200 Landing Gear Module	6
Mavic Air		pcs
41228	DJI Mavic Air Aircraft Accessory Pack (GKAS)	2
41229	DJI Mavic Air Aircraft Screw Pack (GKAS)	2
41220	DJI Mavic Air Front Left Arm (Black)	9
41224	DJI Mavic Air Front Left Arm (Red)	4
41222	DJI Mavic Air Front Left Arm (White)	8
41221	DJI Mavic Air Front Right Arm (Black)	6
41225	DJI Mavic Air Front Right Arm (Red)	3
41223	DJI Mavic Air Front Right Arm (White)	6
41226	DJI Mavic Air Rear Left Arm	6
41227	DJI Mavic Air Rear Right Arm	6
41231	DJI Mavic Air Vibration Absorbing Board	5
Mavic Pro		pcs
40868	DJI Mavic Aircraft Frame Flexible Flat Cable (GKAS)	5
40874	DJI Mavic Pro Back Left Motor Arm (GKAS)	6
40875	DJI Mavic Pro Back Right Motor Arm (GKAS)	7
40867	DJI Mavic Compass Board (GKAS)	6
40871	DJI Mavic Fan (GKAS)	5
40866	DJI Mavic Flight controller ESC board (GKAS)	1
41150	DJI Mavic Front Axis	8
40870	DJI Mavic Front Vision (GKAS)	2
40966	DJI Mavic Gimbal Mounting Bracket	8
40876	DJI Mavic Gimbal Vibration Absorbing Board (GKAS)	11
40865	DJI Mavic GPS Module (GKAS)	2
40863	DJI Mavic Middle Frame (GKAS)	10
40960	DJI Mavic Power Board (GKAS)	2
40959	DJI Mavic Pro Aircraft Appearance Sticker (GKAS)	5
40869	DJI Mavic Pro Bottom Shell (GKAS)	4
40961	DJI Mavic Pro Core Board A (GKAS)	1
40872	DJI Mavic Pro Front Left Motor Arm (GKAS)	8
40873	DJI Mavic Pro Front Right Motor Arm (GKAS)	9
40877	DJI Mavic Pro Gimbal & Camera(GKAS) (Pro/Platinum)	6
41217	DJI Mavic Pro Plat Flight Controller ESC module	0
41230	DJI Mavic Pro Remote Controller 5D Button	5
40963	DJI Mavic RC Lower Cover (GKAS)	1
40864	DJI Mavic Pro Upper Shell (GKAS)	5
40962	DJI Mavic Wi-Fi Board (GKAS)	3
CP.PT.S00040	DJI Mavic Power Interface Boards	1
41219	DJI Mavic Pro Platinum Bottom Shell	3
41179	DJI Mavic Pro Platinum Left Front Motor Arm	5
41167	DJI Mavic Pro Platinum Left Rear Motor Arm (PY)	3

41166	DJI Mavic Pro Platinum Middle Frame Module (PY)	7
41177	DJI Mavic Pro Platinum Right Front Motor Arm	4
41172	DJI Mavic Pro Platinum Right Rear Motor Arm (PY)	4
41181	DJI Mavic Pro Platinum Upper Cover (GKAS)	5
Mavic 2		pcs
41370	DJI Mavic 2 Front Arm Axis (right)	4
41383	DJI Mavic 2 Front Arm Module (Left)	4
41385	DJI Mavic 2 Front Arm Module (Right)	4
41371	DJI Mavic 2 Front Cover	4
41378	DJI Mavic 2 Gimbal Mounting Cover	4
41374	DJI Mavic 2 Lower Cover Module	5
41377	DJI Mavic 2 Middle Frame Module	5
41369	DJI Mavic 2 Rear Arm Axis	4
41384	DJI Mavic 2 Rear Arm Axis Bracket (Left)	5
41373	DJI Mavic 2 Rear Arm Axis Bracket (Right)	5
41381	DJI Mavic 2 Rear Arm Module (Left)	3
41387	DJI Mavic 2 Rear Arm Module (Right)	4
41372	DJI Mavic 2 Rear Landing Gear (Left)	4
41379	DJI Mavic 2 Rear Landing Gear (Right)	4
41382	DJI Mavic 2 Upper Cover Module	3
41386	DJI Mavic 2 Pro Gimbal and Camera	2
41375	DJI Mavic 2 Zoom Gimbal and Camera	4
480011	DJI Mavic 2 Battery to Power Bank adpt	3
Phantom 3		pcs
CP.PT.000188	P3 Part 2 Propeller Guard	4
CP.PT.000192	P3 Part 6 HD Camera (adv)	1
	P3 Part 119 - 4K Camera	1
CP.PT.000207	P3 Part 21 57W battery Charger	14
CP.PT.000215	P3 Part 29 Landing gear (Pro/Adv)	13
	P3 Part 35 OFDM Receiver Module	2
	P3 Part 36 VPS (Pro/Adv)	2
CP.PT.000225	P3 Part 39 Camera Vibration Absorbing Ball	5
CP.PT.000226	P3 Part 40 Vibration Absorbing Rubber Ball	1
	P3 Part 41 Screw Set	5
CP.PT.000228	P3 Part 42 Cable Set	1
	P3 Part 43 Sticker Set (all)	2
CP.PT.000232	P3 Part 46 ND4 Filter	1
	P3 Part 47 USB-Port Cable	10
CP.PT.000241	P3 Part 54 HDMI Output Module (Pro/Adv)	8
CP.PT.000242	P3 Part 55 ND8 Filter (Pro/Adv)	1
CP.PT.000243	P3 Part 56 ND16 Filter (Pro/Adv)	3
	P3 Part 67 GPS Module (Sta)	1
	P3 Part 69 5,8G Receiver Antenna (Sta)	4
	P3 Part 71 Landing gear (Sta)	5
	P3 Part 82 Sticker Set (Sta)	3
CP.PT.000268	P3 Part 84 Gimbal lock standard	2
	P3 Part 97 2,4G Receiver Antenna (Sta)	3
	P3 Part 101 LED (Sta)	10
	P3 Part 102 LED (Pro/Adv)	8
	P3 Part 106 Center Board Component	4

	P3 Part 117 Damping Rod	7
CP.PT.000227	DJI P3 Part 41 Screw Set	4
CP.PT.000193	DJI P3 Part 7 2312 Motor (CCW) (Pro/Adv)	12
CP.PT.000194	DJI P3 Part 8 2312 Motor (CW) (Pro/Adv)	10
40598	DJI P3 Part 39 Camera Vibr. Absorbing Board (Pro/Ad	15
40648	DJI P3 Part 83 Camera Vibrat. Absorbing Board (Sta)	1
	DJI P3 Part40 Vibrat. Absorbing Rubber Ball	2
40666	DJI Phantom 3 Part 97 2.4g antenna (sta)	1
40667	DJI Phantom 3 Bottom Shell	3
CP.PT.000228	DJI Phantom 3 Cable Set, Part 42	10
CP.PT.000197	DJI Phantom 3 Compass, Part 11	0
40881	DJI Phantom 3 connecting cable set (Sta)	2
40986	DJI Phantom 3 Damping Rod (Part 117)	30
40880	DJI Phantom 3 ESC central board & mc & receiver 5.5ghz	1
40672	DJI Phantom 3 gps module (sta) Part 67	1
CP.PT.000269	DJI Phantom 3 Part 85 Flex Gimbal Flat Cable(Sta)	2
40673	DJI Phantom 3 part1 gps module (pro/adv)	1
40674	DJI Phantom 3 part3 antenna (pro/adv) (4pcs)	0
40675	DJI Phantom 3 part4 inner power port module	2
40575	DJI Phantom 3 Part49 FlexGimbal Flat Cable (Pro/adv)	0
40676	DJI Phantom 3 Part 69 receiver antenna 5.8G (sta) (2pcs)	4
40879	DJI Phantom 3 shell (top & bottom) (sta)	5
40677	DJI Phantom 3 standard aircraft body mainboard(sta)	8
CP.PT.000229	DJI Phantom 3 Sticker Set, Part 43	5
40678	DJI Phantom 3 Top Shell	7
Phantom 4		pcs
40679	DJI Phantom 4 2312S motor single unit (GKAS)	0
	DJI Phantom 4 2312S motor (CCW) part 23	2
	DJI Phantom 4 2312S motor (CW) part 24	1
40682	DJI Phantom 4 ESC board right (GKAS)	2
41271	DJI Phantom 4 Gimbal & Camera refurbished	2
CP.PT.000376	DJI Phantom 4 LED Part 41	27
40964	DJI Phantom 4 Part 27-1 Upper Shell (GKAS)	4
40878	DJI Phantom 4 Part 27-2 middle shell (GKAS)	4
CP.PT.000368	DJI Phantom 4 Part 33 Screw Set	2
	DJI Phantom 4 Part 34 Cable Set	3
CP.PT.000370	DJI Phantom 4 Part 35 Gimbal Lock	3
40645	DJI Phantom 4 Part 44 ESC Center Board(left)	5
40646	DJI Phantom 4 Part 45 ESC Center Board(right)	3
40683	DJI Phantom 4 Part1 GPS module	2
40862	DJI Phantom 4 Part28 downward vision module	4
40684	DJI Phantom 4 Part3 aircraft internal power port module	5
40687	DJI Phantom 4 Part48 main controller single unit	2
40689	DJI Phantom 4 Part49 LED light cover	22
40690	DJI Phantom 4 Part50 flat cable & cable	4
40691	DJI Phantom 4 Part51 forward vision module	2
40692	DJI Phantom 4 Part52 3-in-1 board module	1
40693	DJI Phantom 4 Part53 main controller vibration	4
	DJI Phantom 4 Landing Gear Antenna Cover 1	3
	DJI Phantom 4 Landing Gear Antenna Cover 2	3

	DJI Phantom 4 Landing Gear Antenna Cover 3	3
	DJI Phantom 4 Landing Gear Antenna Cover 4	3
CP.PT.S00024	DJI Phantom 4 9450S QR Propeller Base CW	8
	P4 Part 1 GPS modul	1
CP.PT.000337	P4 Part 2 Propeller Guard	7
CP.PT.000343	P4 Part 8 Battery Charging Hub	7
CP.PT.000334	P4 Part 9 100W Power Adaptor (without AC cable)	1
CP.PT.000353	P4 Part 18 Remote Controller uden box	1
CP.PT.000358	P4 Part 23 2312S Motor_CCW_	5
CP.PT.000359	P4 Part 24 2312S Motor_CW_	2
	P4 Part 27 Shell	1
	P4 Part 28 Downward Facing Vision Positioning Module	1
CP.PT.000366	P4 Part 31 Mobile Device Holder	3
CP.PT.000368	P4 Part 33 Screw Set	3
CP.PT.000370	P4 Part 35 Gimbal Lock	5
CP.PT.000371	P4 Part 36 Flexible Gimbal Flat Cable	3
	P4 Part 41 LED	14
CP.PT.000382	P4 Part 47 Replica Model	1
	P4 Part 50 cable mix ???	2
Phantom 4 Pro		pcs
40954	DJI Phantom 4 Pro 3-in-1 Board Module (GKAS)	1
41232	DJI Phantom 4 Pro Compass Connection Cable	4
40955	DJI Phantom 4 Pro Flat Cable & Cable (GKAS)	4
40956	DJI Phantom 4 Pro Forward Vision Module (GKAS)	2
40949	DJI Phantom 4 Pro Gimbal Vibration Absorbing Board	5
40942	DJI Phantom 4 Pro GPS Module (GKAS)	2
41419	DJI Phantom 4 Pro Landing Gear Antenna Cover 1	13
41392	DJI Phantom 4 Pro Landing Gear Antenna Cover 2	13
41393	DJI Phantom 4 Pro Landing Gear Antenna Cover 3	13
41420	DJI Phantom 4 Pro Landing Gear Antenna Cover 4	13
40953	DJI Phantom 4 Pro LED Cover (4pcs) (GKAS)	6
40946	DJI Phantom 4 Pro Left & Right Landing Gear (GKAS)	4
40951	DJI Phantom 4 Pro Left ESC Board (GKAS)	1
40950	DJI Phantom 4 Pro Main Controller (GKAS)	2
41170	DJI Phantom 4 Pro Obsidian 2312S Motor (Black)	8
40943	DJI Phantom 4 Pro Power Interface Module (GKAS)	2
40957	DJI Phantom 4 Pro Rearward Vision Module (GKAS)	2
40952	DJI Phantom 4 Pro Right ESC Board (GKAS)	1
40944	DJI Phantom 4 Pro Sub G Antenna (GKAS)	5
40947	DJI Phantom 4 Pro Upper Shell (GKAS)	4
41233	DJI Phantom 4 Pro V2.0 Gimbal & Camera	1
41269	DJI Phantom 4 Pro V2.0 Left Landing Gear	4
41234	DJI Phantom 4 Pro V2.0 Long Gimbal Flat Cable	4
41270	DJI Phantom 4 Pro V2.0 Right Landing Gear	9
41235	DJI Phantom 4 Pro V2.0 screw pack (GKAS)	4
41165	DJI P4P Obs. Middle Frame (black)	5
41168	DJI P4P Obs. Landing Gear Antenna Cover 1 (Black)	11
41173	DJI P4P Obs. Landing Gear Antenna Cover 2 (Black)	1
41174	DJI P4P Obs. Landing Gear Antenna Cover 3 (Black)	1
41169	DJI P4P Obs. Landing Gear Antenna Cover 4 (Black)	9

41178	DJI P4P Obs. Left Landing Gear Module (black)	4
41175	DJI P4P Obs. Right Landing Gear Module (black)	5
41185	DJI P4P Obs. Upper Cover (with logo) (Black) V3	4
SPARK		pcs
41083	DJI Spark Gimbal and Camera Module	3
	DJI Spark LED covers + mounting rings (FL,FR,BL,BR)	3
	DJI Spark Top-Shells (red, blue, yellow, green, white,)	15
Focus		
CP.ZM.000238	Focus Remote controller for Inspire, PRO & RAW	1
CP.ZM.000287	Focus Part 3 2.4G Antenna	2
CP.ZM.000292	Focus Part 8 Lens Gear Ring (60MM)	1
CP.ZM.000293	Focus Part 9 Lens Gear Ring (70MM)	1
CP.ZM.000296	Focus Part 12 Neck Strap	1
CP.ZM.000298	Focus Part 14 Motor Quick-release Mount	1
	Focus Part 15 Motor Quick-release Mount (extended by 40mm)	1
CP.ZM.000300	Focus Part 16 Motor Gear(MOD 0.8)	1
Ronin		
CP.ZM.000098	Ronin Part 4 Lens Support Thumbscrew	1
CP.ZM.000100	Ronin Part 6 Battery Charger	4
CP.ZM.000104	Ronin Part 10 Clamb Knob (6pcs)	3
CP.ZM.000105	Ronin Part 11 Vertical Bar Clamb (2Pcs)	1
CP.ZM.000106	RoninPart 12 Base Clamb Assembly	2
CP.ZM.000111	Ronin Part 17 Power Distribution Box	1
CP.ZM.000113	Ronin Part 19 Camera Screw 1/4 (2pcs)	1
CP.ZM.000114	Ronin Part 20 Camera Screw 3/8 (2pcs)	1
CP.ZM.000139	Ronin Part 32 Lens support (103mm)	1
	Ronin (M) Part 41 Battery Power distributor	1
Ronin-M		
CP.ZM.000182	Ronin M Part 6 Center Handle Set	1
CP.ZM.000183	Ronin M Part 7 Locking Knob	1
CP.ZM.000184	Ronin M Part 8 Pitch Interlocking Profile	1
CP.ZM.000185	Ronin M Part 9 Camer lock	1
CP.ZM.000186	Ronin M Part 10 Carbon Tube Adapter	1
CP.ZM.000188	Ronin M Part 12 Regulation Of Interlocking	1
CP.ZM.000190	Ronin M Part 14 Drop Proof Kit	1
CP.ZM.000193	Ronin M Part 17 Remote Controller	1
CP.ZM.000195	Ronin M Part 19 Monitor mount	1
CP.ZM.000198	Ronin M Part 22 Charger	1
CP.ZM.000203	Ronin M Part 27 Mobile Device Holder	1
CP.ZM.000229	Ronin M Part 29 25W BATTERY CHARGER (EU)	1
Osmo		
CP.ZM.000237	Osmo Part 4 Car Mount	4
CP.ZM.000239	Osmo Part 5 Straight Extension Arm	1
CP.ZM.000246	Osmo Part 10 Intelligent Battery Charger(EU)	8
CP.ZM.000260	Osmo Part 26 Carry Case	2
CP.ZM.000279	Osmo Part 35 - Articulating Locking Arm	1
CP.ZM.000307	Osmo Part 38 - Quick Release 360 Mic Mount	3
CP.ZM.000308	Osmo-Inspire Part 39 - Gimbal Cover	4
CP.ZM.000310	Osmo Part 40 - Accessory for Universal Mount - Rotatable Cold Shoe for Universal Mount	3

CP.ZM.000311	Osmo Part 41 - Accessory for Universal Mount - 1/4" & 3/8" Mounting Adapter for Universal Mount	2
CP.ZM.000321	Osmo Part 44 - DJI FM-15 FlexiMic	30
CP.ZM.000344	Osmo Part 47 Z-Axis	2
CP.ZM.000360	Osmo part 49 External Battery Extender	4
CP.ZM.000364	Osmo Part 50 Battery (2PIN) ti DC Power Cable	2
CP.ZM.000363	Osmo Part 51 Battery (10PIN) ti DC Power Cable	2
Div.& ZENMUSE		pcs
ZenmuseX5-part3	ZENMUSE X5 Balancing Ring for Panasonic 15mm,F/1.7 ASPH PZENMUSE	5
ZenmuseX5-part4	ZENMUSE X5 Balancing Ring for Olympus 17mm f1.8 Lens	4
ZenmuseX5-part5	ZENMUSE X5 Balancing Ring for Olympus 14-42 f3.5-6.5 EZ Lens	4
CP.ZM.000024	DJI Zenmuse H3-2D	2
CP.ZM.000054	DJI Zenmuse ZH3-2D, Part 37	14
CP.ZM.000070	DJI ZH3-3D Cable Pack Pa	5
CP.ZM.000152	DJI ZH4-3D Cable Pack Package	4
CP.ZM.000151	DJI ZH4-3D Screws Pack	5
CP.WK.000036	DJI A2 Can-Bus Cable A2	1
CP.AL.000015	DJI Remote Controller Cables Part8 LightBridge	2
CP.ZM.000088	DJI Lightbridge Z15-Gh4 HDMI Cable Part 11	3
	DJI Lightbridge 2 Antennas&Antenna Holder Part 12	2

Can't find a DJI product / accessory / spare-part in our WH ? Have a look and see if we have it here!

Orig. DJI Spare Parts in Boston WH – RMA workshop stock inventory only. Actualized pr.

see on top

Here our available DJI spare-parts, which are NOT listed in our official web-shop.

How to order:

- 1) In the spare-part list copy the whole line of the product(s) you want
- 2) Paste them into a mail to Fritz (FF) ff@boston.dk – adjust the number of pieces you want to buy
- 3) Add the delivering address and your Signature. NB: INCLUDE your Boston customer account-nr.
- 4) FF replies with a price proposal.
- 5) After accept we create an order confirmation, send the products and invoice the normal way.
- 6) The list is actualized after every order confirmation and whenever new products are added.